
Operation Manual VD35 / VD36

DISPLAY AND CROWN/ BUTTON OPERATION



			VD35	VD36
Local Time	Time Indication	Hour hand	Center hour hand	
		Minute hand	Center minute hand	
		Second hand	Center second hand	
		Date window	0	X
	Time setting (by turning CROWN)	Crown at:		
		1st click	Date setting	Time setting
		2nd click	Time setting	X
Dual Time	Time Indication	Hour hand	12H subdial hand (24 hr)	
		Minute hand	6H subdial hand	
	Time setting	Crown at :		
	(by pushing BUTTONS)	Normal position	Button A: -1 hour / push Button B: +1 hour / push	
		2nd click (VD35) 1st click (VD36)	Button A: -1 minute / push Button B: +1 minute / push	

ADJUSTING DUAL TIME HANDS POSITION

- After setting or changing the battery, before setting the till lual time minute hand are at the "0" (12 o'clock) position. efore setting the time, check if the dual time hour hand and
- " If either the dual time hour hand or the dual time minute hand is not at the "0" position, reset it/them following the procedure shown below:
- Pull out the crown to second click (VD35) / first click (VD36)
 Keep the buttons A & B pressed at the same time for more than 2 seconds, then release the buttons.
 Dual time hands move and return to where they were

QII Droducte

This is a watermark for the trial version, register to get the full one!

Benefits for registered users:

- 1.No watermark on the output documents
- 2.Can operate scanned PDF files via OCR
- 3.No page quantity limitations for converted PDF files

Remove Watermark No

Operation Manual VD35 / VD36

3) Press button A or B to reset the dual time hands to "0" position.

3) Press button A or 8 to reset the dual time hands to "U" position.
*Button A: dual time hour hand moves clockwise
Button B: dual time hour hand moves clockwise
*The dual time hands move quickly if the respective buttons are kept pressed.
4) Push the crown back in the normal position.

LOCAL TIME SETTING

- 1) Pull out the crown to second click (VD35) / first click (VD36) when the second hand is at the 12 o'clock
- position.
 2) Turn the crown to set the hour and minute hands. (make sure AM/PM is set correctly).
 3) Push the crown back in the normal position in accordance with a time signal.

Note: * The moment the date changes is midnight.

DUAL TIME SETTING

* When moving to a country or area in a diffe country / area : rent time zone, adjust the dual time hands to that

[Quick set the dual time]

- 1) Crown at normal position.
 2) Adjust the time by pressing the button A or B.
 Button A: 1 hour / push
 Button B: +1 hour / push

- [Precise adjustment of the dual time]
 1) Pull out the crown to second click (VD35) / first click (VD36) when the second hand is at the
- 1) Pull out the crown to second click (VD35) / firs 12 o'clock position. 2) Adjust the time by pressing the button A or B. Button A: -1 minute / push Button B: +1 minute / push

3) Push the crown back in the normal position in accordance with a time signal.

DATE SETTING (VD35 only)

- * Before setting the date, be sure to set the time.
- 1) Pull out the crown to the first click.
- Turn the crown clockwise until the desired date appears. 3) Push the crown back in the normal position
- - Do not set the date during any time between 9.00 PM. and 1:00 A.M. Otherwise, the date may not change properly. If it is necessary to set the date during that time period, first change the time to any time outside it, set the date and then reset the correct time.

SII Products